

# Grease Sampling

## MGT-01-008

---




Fig 1. Filled Grease Thief with cap

1. Use the wide end of the spatula to remove any dirt or debris.
2. Remove plunger from syringe.
3. Use narrow end of spatula to collect sample (~2 g) and fill syringe.
4. Return the plunger to the syringe and use syringe to fill the Grease Thief (see diagram). **\*An incorrectly filled Grease Thief may affect results.\***
5. Gently place cap on Grease Thief.
6. Place Grease Thief into provided shipping tube.
7. Affix completed equipment label, including baseline name, or prepaid barcode label to shipping tube.
8. If using prepaid barcodes, log all sample information into MRG Navigator (including baseline).
9. Send samples back to MRG labs for analysis.

MRG Labs  
410 Kings Mill Road  
York, PA 17401, USA  
Phone: 1-717-843-8884  
Fax: 1-425-696-8725  
[www.mrgcorp.com](http://www.mrgcorp.com)