



## Directions for MRG Navigator

---

- Collect sample using supplies from Grease Thief or Oil sampling kit.
- Affix the barcode equipment label to the sample container. This label uniquely identifies your sample.
- Using a PC or mobile device, navigate to **[mrgnavigator.com](http://mrgnavigator.com)**.
- Sign in with your username and password. Contact MRG Labs at **[\(717-843-8884\)](tel:717-843-8884)** if you do not have an account.
- Choose Grease or Oil from SAMPLES
- Record your samples in Navigator **PRIOR** to sending.
  - \* Click NEW and enter all known sample information, including the grease or oil used in the equipment (IDENTIFIED BASELINE).
  - \* If there are multiple samples to enter: Download the excel template, enter all sample information, and upload the completed file.
- Follow the progress of your samples and see completed results by logging back in at any time. Data may be viewed online, as an excel file, or in individual PDF reports.

MRG Labs  
410 Kings Mill Road  
York, PA 17401, USA  
Phone: 1-717-843-8884  
**[www.mrgcorp.com](http://www.mrgcorp.com)**